

LED Explanation

Power

Power

On: Power on Off: Power off

Link/Act




1000M (Green) On: Running at 1000Mbps Flashing: Transmitting/receiving data RE/

–**10/100M (Yellow) On:** Running at 10/100Mbps **Flashing:** Transmitting/receiving data

Note: For simplicity, we will take TL-SG108E for example throughout this Guide.

Installation Guide

5/8-Port Gigabit Unmanaged Pro Switch TL-SG105E/TL-SG108E



Configuration

The switch is plug and play. To manage the switch, you can use the Web-based GUI or the configuration utility. The utility is only supported on Windows now.

Using the Web-based GUI

- 1. Prepare your computer with a static IP address 192.168.0.x ("x" ranges from 2 to 254), and a subnet mask 255.255.255.0.
- 2. Visit the Web-based GUI with the default IP address of the switch http://192.168.0.1, and log in with admin as both user name and password. Then configure the switch on the GUI.
- 3. It's recommended to configure the IP address of the switch properly to avoid any IP address conflict before connecting the switch to your network.

Using the Configuration Utility

1. Download the Unmanaged Pro Configuration Utility on the product's Support page at http://www.tp-link.com. 2. Decompress the downloaded file, run the installation wizard and follow the prompts to install the Unmanaged Pro Configuration Utility.

3. Double click the icon on the desktop, and the utility home page

the local network.

displays a list of TP-Link switches on

Welcome to the InstallSheld Worked for Unnerspecified Utility The InstallSheld/work of Install Instances Congruence Utility on your computer. To continue, clock Next
< Back Next> Cancel

Discented Switz	ibos					
Product	Device Description	MAC Address	IP Address	Located on IP Network	IP Setting	Log
TL-SG106E	TL-90195E	88-45-25-A0-FS-73	192,168,0,1	192,168,0,146	0	2

- 4. Make sure the switch that you want to manage is in the same subnet as your computer. You can click 🏶 to configure the switch's IP address.
- 5. Double click the switch that you want to configure. Next enter the username and password (both **admin**) for it. Then use the utility to configure the switch.

For more details, please refer to the **User Guide** and the **Unmanaged Pro Configuration Utility User Guide** on the product's Support page.

Specifications

General Specifications

Standard IEEE802.3i, IEEE802.3u, IEEE802.3ab, IEEE802.3x, IEEE802.1p, IEEE802.1q				
Protocol	CSMA/CD			
Data Transfer Rate	Ethernet: 10Mbps (Half Duplex), 20Mbps (Full Duplex) Fast Ethernet: 100Mbps (Half Duplex), 200Mbps (Full Duplex) Gigabit Ethernet: 2000Mbps (Full Duplex)			
Network Media (Cable)	10Base-T: UTP category 3, 4, 5 cable (maximum 100m) EIA/TIA-568 100 Ω STP (maximum 100m) 100Base-TX: UTP category 5, 5e cable (maximum 100m) EIA/TIA-568 100 Ω STP (maximum 100m) 1000Base-T: UTP category 5e cable (maximum 100m) EIA/TIA-568 100 Ω STP (maximum 100m)			
Interface	5/8 10/100/1000Mbps Auto-Negotiation RJ45 Ports			
LED indicators	Power, 10/100M LED, 1000M LED			
Transfer Method	Store-and-Forward			
MAC Address Learning	Automatically learning, automatically aging			
Frame Forward Rate	10Base-T: 14881pps/Port 100Base-Tx: 148810pps/Port 1000Base-T: 1488095pps/Port			

Environmental and Physical Specifications

Operating Temperature	0°C to 40°C (32°F to 104°F)		
Storage Temperature	-40°C to 70°C (-40°F to 158°F)		
Operating Humidity	10%RH to 90%RH non-condensing		
Storage Humidity	5%RH to 90%RH non-condensing		

FC FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures: • Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/ TV technician for help.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1) This device may not cause harmful interference.

2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CE Mark Warning

This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures. TP-Link hereby declares that the device is in compliance with the essential requirements and other

relevant provisions of directives 2014/30/EU, 2014/35/EU, 2009/125/EC and 2011/65/EU. The original EU declaration of conformity may be found at http://www.tp-link.com/en/ce

Industry Canada Statement

CAN ICES-3 (B)/NMB-3(B



Продукт сертифіковано згідно с правилами системи УкрСЕПРО на відповідність вимогам нормативних документів та вимогам, що передбачені чинними законодавчими актами України

EAC

Safety Information

- Keep the device away from water, fire, humidity or hot environments
- Do not attempt to disassemble, repair, or modify the device.
- Do not use damaged charger or USB cable to charge the device.

Frequently Asked Questions (FAQ)

Q1. Why is the Power LED not lit?

The Power LED should be lit when the power system is working normally. If the Power LED is not lit, please try the following:

A1: Make sure the power adapter is connected to the switch with power source properly

A2: Make sure the voltage of the power supply meets the requirements of the input voltage of the switch.

A3: Make sure the power source is ON.

Q2. Why is the Link/Act LED not lit while a device is connected to the corresponding port?

Please try the following:

A1: Make sure that the cable connectors are firmly plugged into the switch and the device.

A2: Make sure the connected device is turned on and works normally.

A3: The cable must be less than 100 meters long (328 feet).



For technical support and other information, please visit http://www.tp-link.com/support, or simply scan the QR code.

Some models featured in this guide may be unavailable in your country or region. For local sales information, visit http://www.tp-link.com.

- Do not use any other chargers than those recommended.
- Adapter shall be installed near the equipment and shall be easily accessible.
- Li Use only power supplies which are provided by manufacturer and in the origin packing of this product. If you have any questions, please don't hesitate to contact us.

BSMI Notice

- 安全諮詢及注意事項

- 女主部尚及注息争項
 請使用原裝電源快應器或只能按照本產品注明的電源類型使用本產品。
 清潔本產品之前請先拔掉電源線。請勿使用液體、噴霧清潔劑或濕布進行清潔。
 注意防潮,請勿將水或其他液體潑灑到本產品上。
 插槽與開口供通風使用,以確保本產品的操作可靠並防止過熱,請勿堵塞或覆蓋開口。
 請勿將本產品置放於靠近熱源的地方。除非有正常的通風,否則不可放在密閉位置中。
 請不要私自打開機殼,不要嘗試自行維修本產品,請由授權的專業人士進行此項工作。

限用物質含有情況標示聲明書

学日二世 白 塚	限用物質及其化學符號					
產品元件名稱	鉛 Pb	鎘 Cd	汞 Hg	六價鉻 CrVI	多溴聯苯 PBB	多溴二苯醚 PBDE
PCB	0	0	0	0	0	\bigcirc
外殼	0	0	0	0	0	0
電源適配器	—	0	0	0	0	0

備考1."超出0.1 wt%"及"超出0.01 wt%"系指限用物質之百分比含量超出百分 比含量基準值。

- 備考2. ℃系指該項限用物質之百分比含量未超出百分比含量基準值。 備考3. "一"系指該項限用物質為排除項目。

Explanation of the symbols on the product label

